



Speaker Front On Top Panel Centered Left of Buttons 5/8" H x 1-1/4" W

*Blue border will not print