



### Colorprint

Clip Top/Left Aligned W/Top Of Clip 3/4 Down From Top Of Pen  
(H 1" X L 0.25")

Clip Top/Left Centered On Cap  
(H 0.25" X L 1")

Clip Top/Left Centered Under Clip  
(H 0.25" X L 1")

Clip Top/Right Primary Centered On Cap  
(H 0.25" X L 1")

Clip Top/Right Primary Centered Under Clip  
(H 0.25" X L 1") *shown by default*

### Laser Etching

Clip Top/Left Aligned W/Top Of Clip 3/4 Down From Top Of Pen  
(H 1" X L 0.25")

Clip Top/Left Centered On Cap  
(H 0.25" X L 1")

Clip Top/Left Centered Under Clip  
(H 0.25" X L 1")

Clip Top/Right Primary Centered On Cap  
(H 0.25" X L 1")

Clip Top/Right Primary Centered Under Clip  
(H 0.25" X L 1")

Laser Etching Initials

Clip Top/Right Primary Centered On Cap

Laser Etching Name

Clip Top/Right Primary Centered On Cap

Box Around Imprint **WON'T PRINT**  
Shows **Maximum** Imprint Area



**Most accurate**  
when printed.

THIS SHOULD  
MEASURE  
ONE INCH



If anything is unclear in regards to how the imprint will appear on the requested product, please call. **We are not responsible for misinterpretations of this proof.**