



Imprint Area: Speaker Front Centered on Top to Left of Buttons 1" H x 1-1/4" W

*Blue border will not print